

SLI-80

OPERATING MANUAL

NOTE:

Before installing your new SLI-80, please read this manual carefully as it will inform you of the SLI-80's specifications, proper installation procedures and operation procedures. Also included in this manual are guidelines on how to properly service and care for your new SLI-80.

SLI-80

INTEGRATED STEREO AMPLIFIER

Congratulations! You have purchased one of the most exotic integrated stereo audio amplifiers available. Within its power range, the SLI-80 displays the operating characteristics of a true "high-end" amplifier. Careful design, parts selection and proper circuit topologies contribute to incredible reliability and enjoyment.

For the technically minded, a review of the circuit in your new SLI-80 is in order. Your new SLI-80 integrated stereo amplifier operates in a class AB1 mode utilizing a negative fixed bias supply. The KT-88/6550 output tubes are configured in push-pull. The triode mode provides 50 watts per channel of output audio power and switching the ultra-linear mode yield 80 watts of output power per channel. In the opinion of the Cary Audio designer the triode mode is the best sounding.

The output transformers in your SLI-80 is the most important component in the amplifier and has been specifically designed by Cary Audio for use in the SLI-80. Negative feedback is derived from a separate winding on the output transformer. This feedback winding and circuitry is used to reduce the noise floor and improve the speaker damping characteristics. Only 4 dB of feedback is utilized. The phase inverter is a self-balancing split load configuration utilizing the 6SN7 octal base dual triode. The preamplifier circuit is a resistive coupled class A triode voltage amplification stage. The power supply in the SLI-80 features a 200% duty cycle EI laminate power transformer. The high voltage section features full wave vacuum tube (CV-729/5U4) rectification (not cheap voltage doublers used in many amplifiers) to a PI-L capacitive network. The input signal from the volume control is direct coupled (DC) to the first grid of the 6922. There are no coupling capacitors in line with the input signal on the SLI-80. The sub-woofer output is derived from a voltage divider network on the input stage of the SLI-80.

A great deal of attention during design of your new SLI-80 was concentrated on the "overload recovery" ability of the amplifier. The ability of an amplifier to instantly recover from clipping is much more important than is commonly believed. In the power war of amplifier manufactures the mentality is focused on high and then even higher power output to solve the clipping problem.

SPECIFICATIONS

Operating the SLI-80 stereo integrated amplifier is a simple procedure, since each unit is designed for long term stability in virtually any home operating situation. Therefore, if the unit is operated outside the parameters outlined in this owner's manual, damage may result. Please read this manual carefully before putting your new Cary Audio Design SLI-80 in operation. The following definitions are applicable to this manual. These definitions must be followed explicitly.

WARNING HAZARD PRESENTS PERSONAL INJURY OR DEATH

Caution

EQUIPMENT DAMAGE MAY OCCUR BUT NOT PERSONAL INJURY

Note

Proper performance of the amplifier cannot be ensured if disregarded

1.2 Specifications

The following section describes the SLI-80 basic specifications. Specs are subject to change without notice or obligation.

DIMENSIONS: 7"H x 17"W x 16"D

WEIGHT: 42 lb..

CIRCUIT TYPE: Push-Pull Ultralinear Amplification in Pure Class AB1

POWER OUTPUT: 50 watts - Triode

80 watts - Ultralinear

INPUT SENSITIVITY: .45 volts for full output

INPUT IMPEDANCE: 100,000 ohms

NOISE AND HUM: 82db below rated output

FREQUENCY RESPONSE (at full power output): 19Hz to 23Khz +/- .5db

VOLUME: Dual precision potentiometer controlling volume of both channels

BALANCE: Dual precision potentiometer to balance between left and right channel

SELECTOR: Selection of line inputs for listening. CD, AUX 1, & AUX 2

HEADPHONE JACK: 1/4" Jack for headphones

OUTPUT/HEADPHONE SWITCH: To switch between headphones and main out.

1.4 Rear Apron Features

INPUTS CD, AUX1, & AUX 2: Signal input connection via shielded interconnect cable

4/8 OHM SWITCH: Toggle switch for 4 and 8 ohm taps.

SUB-WOOFER OUTPUT: Voltage Divider Linear Network for Driving Active Sub-Woofers

SPEAKER OUTPUT: 5-way binding posts provide the output to the speaker system. Red = +, Black = -

AC: 3- conductor shielded power detachable cord to AC power mains.

CAUTION

EQUIPMENT DAMAGE MAY OCCUR WITH IMPROPER FUSES

AC FUSE: This is an overcurrent protection fuse for the SLI-80.

Never replace with any other fuse than 3 AMP SLOW BLOW!

250 VOLT! (2 AMP SLOW BLOW ON 220 VAC OPERATION)

TUBE FUSE: This is a protection fuse for the output tubes. Never replace with any other fuse than a .5 amp fast blow! 250 volt.

CAUTION

NEVER REMOVE / INSERT AC LINE CORD WHEN THE UNIT IS ON

TUBES: 2-6922 Input Buffer Preamp

2- 6SN7 Pre-Driver/Phase Inverter

4-6550 Output tubes

2- CV729/5U4 Rectifiers

POWER TRANSFORMERS: 1- EI laminated, 200% duty cycle

OUTPUT TRANSFORMERS: 2-EI laminated, Silicon Impregnated

RESISTORS: 1% metal film

CAPACITORS: polypropylene

POWER SUPPLY CAPACITORS: 2 - 1200 MFD @ 450 volts

6 - 10 MFD @ 450 volts film & foil

AC CORD: 3 conductor shielded detachable

AC POWER REQUIREMENTS: 117/234 volts AC 50/60Hz

POWER CONSUMPTION:

166 watts operate

83 watts in stand-by

WARM-UP TIME: 3 minutes

BREAK-IN PERIOD: 100 hours of music playing time

FINISH: Textured Black Steel Chassis

FRONT PANEL: Machined, Black Anodized aluminum

1.3 Front Panel Features

POWER OFF SWITCH:

Rotary switch turns on AC mains and high voltage on "in operate" position

LED: Indicates high voltage on

INSTALLATION

This section describes the unpacking and installation procedures for the SLI-80 amplifier.

WARNING

MAKE NO ATTEMPT TO PUT THE SLI-80 AMPLIFIER IN SERVICE WITHOUT THE BOTTOM PLATE ATTACHED - CONTACT WITH VOLTAGE IN THE SLI-80 CAN BE FATAL!!!!!

2.1 Unpacking

All shipping containers have been specifically designed to protect their contents and special care has been taken to prevent damage under normal shipping conditions. Mishandling should be evident upon inspection of the shipping container. If damage is found after visual inspection, take care not to destroy the evidence. If necessary, document the damage with photographs and contact the transport carrier immediately.

Carefully remove your new SLI-80 stereo integrated amplifier from its packing carton, and examine it closely for signs of shipping damage. It is recommended to save all original packing cartons to protect your amplifier from damage should you wish to store it or ship it for after-sales service.

2.2 Warranty Card

Fill out the enclosed warranty registration card and return it to Cary Audio Design, Inc. within 10 days of original purchase. Keep your original sales slip with the packing cartons should you ever need it for reference. Failure to register warranty will limit the warranty to one year.

2.3 Amplifier Placement

In general, the location of your new SLI-80 is not critical. Certain precautions must be taken to ensure optimum performance. Avoid extremely hot locations such as near radiators or other heating units. Keep the top of the SLI-80 clear of books, paper or other equipment to protect against overheating!! DO NOT place your SLI-80 in a closed book case - overheating will damage the amplifier! Allow 8 to 10 inches above the unit for proper ventilation.

2.4 Power Requirements

The SLI-80 is designed to operate from house current mains. The design voltage is 117 VAC at 50/60Hz. (Foreign units 234 VAC at 50/60Hz.)

2.5 Cables

The speaker cables from the output posts of the SLI-80 to the speaker system can be any convenient length your set-up requires. Select speaker cables of sufficient size to preserve the outstanding performance capabilities of your SLI-80. Heavy gauge #16 wire is suitable for distances up to 10 feet; #12 for 25 feet. Most audio dealers will have proper speaker cable in stock for this purpose.

OPERATION

Signal input connection is made via the input jacks on the rear of the SLI-80 located on the rear panel. The interconnect cables from the output of the CD player, tuner, etc. can be any convenient length your set-up requires. The choice of a high quality interconnect cable is important. Once again, your audio dealer will have the proper cables in stock for this purpose.

3.1 Operation

Your new SLI-80 is ready for operation after the speaker and interconnect cables have been installed. Refer to the tube placement sheet at the end of this manual for proper installation.

3.2 4/8 OHM Switch

Select the proper impedance that is called for in you speaker specification. Make sure that both left and right channels are the same. An improper setting may not yield peak preformance.

3.3 AC Off/Operate Switch

Simply turn the rotary switch to the "operate" position. Observe that all 10 tubes are lit (filaments).

3.4 Headphone/Output Switch

Make this selection based on which output you want to use. If you are using headphones it would be best to have the headphones installed before switching to headphones. If the music is playing loud and you switch to headphones without headphones in place it may damage the unit.

3.5 Break-In Period

The tubes, capacitors and output transformers take approximately 100 hours of music playing to fully settle in for peak performance. The SLI-80 will seem sterile or thin sounding right out of the box. After the first couple of hours you will notice increased depth and tighter bass. This break-in period defies all engineering theory, but is true with most audio amplifiers.

3.6 Bias Measurement

The bias is factory preset. It is a good idea to measure it during the initial setup to make sure it is set to the specifications provided at the end of this manuel. The AC voltage may be different from one area to the next. Follow the instructions provided. You will need a meter that allows you to read up to 100mA.

WARNING MAKE SURE AMPLIFIER IS UNPLUGGED FROM AC MAINS BEFORE SERVICING

SERVICE AND CARE

4.1 SLI-80 Care and Cleaning

The case and front of the SLI-80 may be cleaned with a soft cloth and Windex or a window cleaner. The frequency of cleaning will be governed by how many hours the SLI-80 is operated and by operating environment cleanliness.

4.2 Tube Replacement

If it becomes necessary to replace the tubes in the SLI-80 amplifier, a matched quartet set of output tubes of the same brand should be used. A new tube kit is available from Cary Audio Design, Inc. You should get a few years or more from the output tubes with everyday usage and many, many years of use from the 6922 & 6SN7 input tubes.

4.3 FACTORY SERVICE

Careful consideration has been given to the design of your SLI-80 amplifier to keep maintenance problems to a minimum. However, it is possible that some problems may arise which cannot be cured by tube substitution. At this point we suggest you contact our Customer Service Department phone number (919)481-4494 to describe your problem in detail. DO NOT return the SLI-80 to the factory without a return authorization number from the Customer Service Department.


SLI-80 Signature Bias Adjustment


Bias Meter Jack

Bias Adjust









Set bias for both sides of the amplifier to 100mA


Insert meter plug into bias jack.

Adjust for 100mA reading on DC current meter.

Readjust to 100mA after after SLI-80 is warmed up for 10 minutes. Remove plug and enjoy the music!

Note: Bias is factory preset; Bias should be reset when installing replacement KT-88 / 6550 tubes.

Triode / Ultra-linear switch settings



Top of Amplifier

4 – 8 ohm switch settings

Ω8 (P)	·	
4Ω	4Ω	

Rear of Amplifier

Cary Audio Design, Inc. will assume no responsibility if the transportation company refuses to pay a damage claim due to your improper packing or lack of insurance should the unit be lost or damaged in shipment.

WARNINGS

MAKE NO ATTEMPT TO PUT THE SLI-80 IN SERVICE WITH THE BOTTOM PLATE REMOVED. CONTACT WITH HIGH VOLTAGES **FOUND** IN THE UNIT BE CAN FATAL!! COMPLETELY REMOVE AC POWER PLUG FROM THE WALL AND ALLOW 30 MINUTES FOR HIGH THE **VOLTAGE CAPACITORS** TO **DISCHARGE** THROUGH BLEEDER RESISTORS BEFORE ATTEMPTING TO CHANGE TUBES OR CLEAN THE INSIDE OF THE AMPLIFIER

CAUTIONS

NEVER REMOVE / INSERT AC PLUG WHEN THE UNIT IS ON OR THE AC POWER SWITCH IS IN THE ON POSITION. OBSTRUCTION OF THE TOP PORTION OF THE SLI-80 WILL RESULT IN TUBES OVERHEATING AND DAMAGE TO THE AMPLIFIER.


!!OBSERVE DIRECTIONS IN THIS MANUAL!!

When in reality the most critical aspect is how fast a recovery an amplifier can achieve after overload. With the incredible dynamic range of live and in turn recorded music even 2000 watts of power is not enough power. Most of the music being listened to in an average listening room is only requiring about 3 watts of power. It is on the transients of loud low frequency program material that tremendous signal voltages will appear at the input of the amplifier. It is in this situation that the overload recovery ability of an amplifier is of critical concern. The SLI-80 will overload symmetrically at any frequency in the audio band-pass. The SLI-80 will also yield faithful reproduction of extremely low frequencies at full output levels. Power transformer, power supply regulation and output transformer design and careful shaping of the overall frequency response curve all play a very important part in the ability of the SLI-80 to recover quickly when overloaded. The high voltage rail will fluctuate no more than a volt between soft and loud passages.

Another technical feature of your new SLI-80, aside from how compact and gorgeous it looks, is the delightful, sensual beauty of the music it recreates. The first thing that will strike you about your new SLI-80 integrated amplifier is the incredible transparency and resolution of detail in the music. The SLI-80's sensual nature is best revealed in the sense of life it displays in female vocalists.

Your new Cary SLI-80 integrated presents music with such presence and directness, you'll be drawn into the music hour after musically satisfying hour. This is the result of circuit techniques, which eliminate any discernible crossover notch at low levels, and also contributes to the freedom from listening fatigue. The SLI-80 will draw you in even further as you realize how lucid and utterly uncolored neutrality reveals delicate nuances in the sound stage.

Enjoy the music and of course please read this complete manual for a complete understanding of trouble free operation.



SLI-80 TROUBLESHOOTING GUIDE

SYMPTOM	CAUSE	REMEDY
Hum or "Buzzing" through speakers	-Ground Loop	-Install 2-pin adapter on A.C. cord to float the ground.
	-Intermittent or poor connection of interconnect ground	-Replace interconnect.
"Popping or Spitting" noise through the speaker	-Noisy tube	-If noise is in one channel, swap one section of tubes at a time until the noise swaps channels. Replace noisy tube.
		-Check bias of output tubes. If high or fluctuating rap idly, replace output tube. (See bias instruction sheet)
AC fuse blows	-Line voltage surge	-Replace fuse.
	-CV729 shorted.	-Replace CV729/5U4
Tube fuse blows	-Shorted output tube	-Replace tube.

UNITED STATES LIMITED WARRANTY

Cary Audio Design, Inc. warrants to the original United States purchaser for use in the United States, that this product shall be free from defects in material (except tubes and AF output transistors) or workmanship for three (3) years from the date of the original purchase.

During the warranty period, Cary Audio Design, Inc. or an authorized Cary Audio Design, Inc. service facility will provide free of charge both parts (except tubes and AF output transistors) and labor necessary to correct defects in material or workmanship.

To obtain such warranty service, the original purchaser must:

- (1) Complete and send in the warranty Registration Card.
- (2) Notify Cary Audio Design, Inc. as soon as possible after the discovery of a possible defect, of:
 - (a) The model number and serial number;
 - (b) The identity of the seller and the approximate date of purchase;
 - (c) A detailed description of the problem, including details on the electrical connection in the associated equipment and the list of such equipment.
- (3) Deliver the product to Cary Audio Design, Inc. or the nearest authorized service facility, or ship the same in its original container or equivalent, fully insured and the shipping charges prepaid.

Correct maintenance, repair and use are important to obtain performance from this product. Therefore, carefully read the Instruction Manual. This warranty does not apply to any defect that Cary Audio Design, Inc. in its sole discretion determines is due:

- (1) Improper maintenance or repair, including the installation of parts or accessories that does not conform to the quality and the specifications of the original parts.
- (2) Misuse, abuse, neglect or improper installation.
- (3) Accidental or incidental damage.

WARRANTY DISCLAIMER

Except for the express warranties stated herein, Cary Audio Design, Inc. disclaims all other warranties including, without limitation, all implied warranties of merchantability and fitness for a particular purpose.

EXCLUSIVE REMEDY

Notwithstanding the foregoing, the purchaser's exclusive remedy for any breach of warranty, express or implied, is limited to the repair or replacement of the defective unit or the refund of he purchase price, at the option of Cary Audio Design, Inc. Under no circumstances is Cary Audio Design liable for incidental or consequential damages. Any implied warranties imposed by law terminate (1) year from the date of the original purchase.

FOREIGN PURCHASERS

Cary Audio Design, Inc. warrants its merchandise to purchasers in the United States for use in the United States. It provides no other warranties. If you are a foreign purchaser, consult with your dealer to determine whether your dealer provides any warranty.

The foregoing constitutes Cary Audio Design, Inc.'s entire obligation with respect to this product, and the original purchaser and any user or owner shall have no other claim for individual or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation and exclusion may not apply to you.

This warranty gives legal rights and you may also have other rights which vary state to state.



111-A Woodwinds Industrial Court Cary, NC 27511 USA

Phone: 1-919-481-4494

Fax: 1-919-460-3828

www.caryaudio.com

info@caryaudio.com