



MS-1 Upgrade procedure

The DVD that came with your MS-1 is called a restore DVD. It is designed to reload the MS-1 software as it was out of the box, without disturbing your music collection.

Occasionally, we will release updates that will add new features or address operational issues. Once the new update is downloaded and burned to a DVD, it will act in the same fashion as the original restore disk, but installs the latest version of the operating system along with new features and functions. After downloading the new software, this will be your disk for future restoration and the original can be discarded.

Choose the version for the model MS-1 you have.

**If your serial number is #100300 or lower, download the version “A” of the disc image.
If your serial number is #100301 or higher, download the version “B” of the disc image.**

Download-

Download the latest version of the DVD from our site. Again, this can take several hours so plan accordingly. Once you have downloaded the .iso file, you will need to burn it to a blank DVD.

Burn-

Use the DVD burning software that came with your computer. There are also free burning applications on the web. Select the file you just downloaded and burn it to a blank DVD. Once burning is complete, label the disk with a Sharpie for future use.

NOTE: We recommend using DVD+R media for burning your DVD. We also recommend marking the disk with a marker only and do not affix a paper label to the DVD.

Restore-

Shut down your MS-1 and partially insert the DVD you just burned. Power on the MS-1 and insert the DVD the rest of the way. It will start from the DVD and automatically load the software to the MS-1.

Reboot-

When the DVD has completed the update process, it will eject the DVD from the drive.

At this time you can remove the DVD. Press and hold the power button on the rear of the MS-1 until it turns off. Wait 10 seconds and press the button once again to start the MS-1 up again.

Some music may not appear on the remote right away. As it completes cataloging, the music will be displayed.